



## **safe-T-seat Pad Assembly Instructions**

1. Unbuckle the shoulder straps from the crotch strap buckle.
2. Slide the crotch strap through the slot in the bottom of the pad.
3. Insert the 3 push pins through the 3 holes in the seat pad and fasten them into the 3 holes in the backrest of the safe-T-seat.
4. Enjoy the ride!!